



NOTE:

1. CONTRACTOR TO COORDINATE WITH ARCHITECTURAL FLOOR PLANS FOR FITTING NEW FLOOR DRAIN INTO EXISTING NEWLY SLOPED FLOOR.
2. CONTRACTOR SHALL NOT SAW CUT OR CHIP OUT REBAR OR CONDUIT IN SLAB. IF REBAR OR CONDUIT IS ENCOUNTERED AT OR NEAR WHERE FLOOR IS CHIPPED OUT, IMMEDIATELY INFORM VA.



FLOOR DRAIN DETAIL TYPE 'C'

NTS